


ECOTRAY

ECOTRAY prevents potential leaks from Hydraulic systems dripping onto floors and other internal components. The Skyjack system removes the need for a cumbersome, unsightly “diaper” and is particularly suited for working on sensitive areas, such as decorative flooring, clean rooms and areas where hygiene and concern for chemical contamination are a priority. Unlike other systems that focus on the main hydraulic tray, **ECOTRAY** also protects against leaks from drive motors and steering cylinders.

Skyjack’s **ECOTRAY** has been designed with essential machine functionality in mind.


These essential functions include:

- Pothole protection
- Static strap use
- Access to the emergency stop
- Emergency lowering
- Base controls



SKYJACK
simply reliable

ECOTRAY



KEY FEATURES

- Protects against the whole hydraulic system, not just the main hydraulic tray.
- Avoids cumbersome diaper attachment
- Prioritizes machine functionality
- Protected from jobsite debris damage, forklift handling, etc.
- Available as a factory fit or field install option
- Installed in less than 10 minutes
- Absorbent pads changed in seconds
- **ECOTRAY** label identifies Eco-friendly option fitted

COMPATIBLE MODELS

| | |
|--------|---|
| SJ3215 | ✓ |
| SJ3219 | ✓ |
| SJ3220 | ✗ |
| SJ3226 | ✓ |
| SJ4726 | ✓ |
| SJ4732 | ✓ |
| SJ4740 | ✓ |

Skyjack Head Office

55 Campbell Rd.
 Guelph, ON Canada N1H 1B9
 Sales Inquiries: 1-877-755-4387 (1-877-SJLIFTS)
 Main Switchboard: 1-800-265-2738
 Phone: 519-837-0888
 Fax: 519-837-8104
 Email: skyjack@skyjack.com

Skyjack Parts & Service

2525 Enterprise Circle
 West Chicago, IL 60185 USA
 Phone: 630-262-0005
 Toll Free: 1-800-275-9522
 Fax: 630-262-0006
 Email: service@skyjack.com

ACCESSORYZERS™
www.skyjack.com/accessoryzers